

## Title

How to set Widnwos Firewall?

## I. Introduction

DVR can use the IO device to sense or trigger.

## II. Preparations


Install Windows XP home or professional up to SP2

## III.Steps of Operation


Step 1 : Click Start -> Settings -> Control Panel




Step 2 : Select “Windows firewall”




Step 3 : Click "Advanced" page and select "Local Area Connection" Settings.




Step 4 : Enabled the "Web Server(HTTP),it will show the setting,please copy the name.




Step 5 : Click "Add", copy the name in the same place and keyin 18082 to other places.



Step 6 : Click "Add"



Step 7 : Click "Add",copy the name in the same place and keyin 18083 to other places.



Step 8 : After add 80,18082,18083,click "OK".

